

Filter paper precision filtration filter press

Product Description

The filter chamber of PP plate and frame filter press consists of PP filter plates and PP filter frames arranged in sequence, adopting the form of upper corner feeding. The plate and frame filter press can only be discharged by manually pulling the plate. PP plate and frame filter presses are used for materials with high viscosity, and the filter cloth is often cleaned or replaced. PP plate and frame filter press can be used with filter paper for higher filtration precision.



Product Features


- A. Filtration pressure: 0.5Mpa
- B. Filtration temperature: 45°C/ room temperature; 80°C/ high temperature.
- C. Liquid discharge method: Each filter plate is fitted with a faucet and matching catch basin. The liquid that is not recovered adopts open flow; Close flow: there are 2 dark flow main pipes below the feed end of the filter press and if the liquid needs to be recovered or the liquid is volatile, smelly, flammable and explosive, close flow is used.
- D-1. **Selection of filter cloth material:** The PH of the liquid determines the material of the filter cloth. PH1-5 is acidic polyester filter cloth, PH8-14 is alkaline polypropylene filter cloth.
- D-2. **Selection of filter cloth mesh:** The fluid is separated, and the corresponding mesh number is selected for different solid particle sizes. Filter cloth mesh range 100-1000 mesh. Micron to mesh conversion (1UM = 15,000 mesh---in theory).
- E . Pressing method: jack, manual cylinder, electro-mechanical pressing, automatic cylinder

pressing.

F. Filter cake washing: if it is necessary to recover solids, the filter cake is strongly acidic or alkaline.

Filter Press Model Guidance							
Liquid name	Solid-liquid ratio (%)	Specific gravity of solids	Material status	PH value	Solid particle size (mesh)		
Temperature (°C)	Recovery of liquids/solids	Water content of filter cake	Working hours/day	Capacity/day	Whether the liquid evaporates or not		

Feeding process



PP plate and frame filter press application industries

Gold fine powder, oil and grease decolouration, white clay filtration, gross oil filtration, sodium silicate filtration, sugar products filtration, and other viscosity of the filter cloth is often cleaned fluid filtration.


Filter press ordering instructions

1. Refer to the filter press selection guide, filter press overview, specifications and models, select the model and supporting equipment according to the needs.

For example: Whether the filter cake is washed or not, whether the effluent is open or close, whether the rack is corrosion-resistant or not, the mode of operation, etc., must be specified in the contract.


- 1. According to the special needs of customers, our company can design and produce non-standard models or customized products.
- 3. The product pictures provided in this document are for reference only. In case of changes, we will not give any notice and the actual order will prevail.

Dimension Drawing of Filter paper precision filtration filter press



	Filter	Plate	Chamber	Plate	Filter Frame	Overall	Motor	Overall	dimension	(mm)	Inlet	Outlet/clos	Outlet/open
Model	Area (m²)	Size (mm)	volume (L)	Qty (PCS)	Number (PCS)	Weight (Kg)	Power (Kw)	Length (L)	Width (W)	Height (H)	Size (a)	e flow size (b)	flow size
JYFPPMP-4-450	4		60	9	10	830		2180					
JYFPPMP-8-450	8	450	120	19	20	920		2780					
JYFPPMP-10-450	10	×	150	24	25	9800	2.2	3080	700	900	DN50	DN50	G1/2
JYFPPMP-12-450	12	450	180	29	30	1010		3380					
JYFPPMP-16-450	16		240	39	40	1120		3980					
JYFPPMP-15-700	15		225	18	19	1710	-	2940					
JYFPPMP-20-700	20	700	300	24	25	1960		3300	900	1100	DN65	DN50	G1/2
JYFPPMP-30-700	30	×	450	37	38	2315	2.2	4080					
JYFPPMP-40-700	40	700	600	49	50	2588		4900					
JYFPPMP-30-870	30		450	23	24	2380		3670					
JYFPPMP-40-870	40	870	600	30	31	2725	9	4150	1200	1300	DN80	DN65	G1/2
JYFPPMP-50-870	50	×	750	38	39	3118	4.0	4810	01				
JYFPPMP-60-870	60	870	900	46	47	3512		5370					
JYFPPMP-80-870	80		1200	62	63	4261		6390					

Hoisting diagram of filter press Filter board hoisting diagram



Requirements for use of filter presses

- 1. According to the process requirements to make pipeline connection, and do water inlet test, detect the air tightness of the pipeline;
- 2. For the connection of the input power supply (3 phase + neutral), it is best to use a ground wire for the electric control cabinet;
- 3. Connection between control cabinet and surrounding equipment. Some wires has been connected. The output line terminals of the control cabinet are labeled. Refer to the circuit diagram to check the wiring and connect it. If there is any looseness in the fixed terminal, compress again;
- 4. Fill the hydraulic station with 46 # hydraulic oil, the hydraulic oil should be seen in the tank observation window. If the filter press operates continuously for 240 hours, replace or filter the hydraulic oil;
- 5. Installation of cylinder pressure gauge. Use a wrench to avoid manual rotation during installation. Use an O-ring at the connection between the pressure gauge and the oil cylinder;

- 6. The first time the oil cylinder runs, the motor of the hydraulic station should be rotated clockwise (indicated on the motor). When the oil cylinder is pushed forward, the pressure gauge base should discharge air, and the oil cylinder should be repeatedly pushed forward and backward (the upper limit pressure of the pressure gauge is 10Mpa) and air should be discharged simultaneously;
- 7. The filter press runs for the first time, select the manual state of control cabinet to run different functions respectively; After the functions are normal, you can select the automatic state;
- 8. Installation of filter cloth. During the trial operation of the filter press, the filter plate should be equipped with filter cloth in advance. Install the filter cloth on the filter plate to ensure that the filter cloth is flat and there are no creases or overlaps. Manually push the filter plate to ensure that the filter cloth is flat.
- 9. During the operation of the filter press, if an accident occurs, the operator presses the emergency stop button or pulls the emergency rope;

Main faults and troubleshooting methods

Fault phenomenon	Fault Principle	Troubleshooting		
Severe noise or unstable	1. The oil pump is empty	Oil tank refueling, solve		
pressure in the hydraulic	or the oil suction pipe is	suction pipe leakage		
system	blocked.			
	2. The sealing surface of	Clean sealing surfaces		
	the filter plate is caught			
	with misc.			
	3. Air in the oil circuit	Exhaust air		
	4. Oil pump damaged or	Replace or repair		
	worn			
	5. The relief valve is	Replace or repair		
	unstable			
	6. Pipe vibration	Tightening or reinforcing		
Insufficient or no pressure	1. Oil pump damage	Replace or repair		
in the hydraulic system	2. Pressure adjusted	recalibration		
	incorrectly			
	3. Oil viscosity is too low	Replacement of oil		
	4. There is a leak in the oil	Repair after examination		
	pump system			
Insufficient cylinder	1. Damaged or stuck high	Replace or repair		
pressure during	pressure relief valve			
compression	2 Damaged reversing	Replace or repair		
	valve			
	3 Damaged large piston	replacement		
	seal			
	4. Damaged small piston	replacement		
	"0" seal			
	~ ~ -			

	5. Damaged oil pump	Replace or repair		
		recalibrate		
	6 Pressure adjusted incorrectly	100anuraic		
Insufficient cylinder	1. Damaged or stuck low	Replace or repair		
pressure when returning	pressure relief valve	Replace of Tepan		
pressure when returning	2 Damaged small piston	replacement		
	seal	Тергасеттент		
	3 Damaged small piston	renlacement		
	"0" seal	replacement		
Piston crawling	Air in the oil circuit	Replace or repair		
Serious transmission noise	1. Bearing damage	replacement		
	2. Gear striking or wearing	*		
Serious leakage between	1. Plate and frame	replacement		
plates and frames	deformation	1		
	2 Debris on sealing	Clean		
	surface			
	3. Filter cloth with folds,	Qualified for finishing or		
	overlaps, etc.	replacement		
	4 Insufficient	Appropriate increase in		
	compression force	compression force		
The plate and frame are	1. Filter pressure too high	turn down the pressure		
broken or deformed	2 . High material	Appropriately lowered		
	temperature	temperatures		
	3. Compression force too	Adjust the compression		
	high	force appropriately		
	4. Filtering too fast	Reduced filtration rate		
	5. Clogged feed hole	Cleaning the feed hole		
	6. Stopping in the middle			
	of filtration	of filtration		
The replenishment system	1. The hydraulic control	replacement		
works frequently	check valve is not tightly			
	closed	D 1		
	2. Leakage in the cylinder	Replacement of cylinder seals		
Hydraulic reversing valve	Spool stuck or damaged	Disassemble and clean or		
failure	Spoot stuck of dufflaged	replace the directional		
1011010		valve		
The trolley can't be pulled	1, Low oil motor oil circuit	adjust		
back because of the back	pressure	J		
and forth impact.	2 The pressure relay	adjust		
_	pressure is low			
Failure to follow	1	Panair or ranlaga		
1 - 10110 W	Failure of a component of	Repair or replace		

	electrical system	inspection			
Diaphragm damage	1, insufficient air pressure	Reduced press pressure			
	2. Insufficient feed	Pressing after filling the			
		chamber with material			
	3 . A foreign object has	foreign matter removal			
	punctured the diaphragm.				
Bending damage to main	1 Poor or uneven	Refurbish or redo			
beam	foundations				

Tel. +86 021-51863216 +86 13916593699

Email. junyifilter@junyigl.com

Address: Shanghai China

Shanghai Junyi filtration equipment Co., LTD