

Mechanical compression filter press

Product Description

Mechanical compression filter press is driven by an electric motor to drive the reducer, through the transmission parts to push the compression plate to press the filter plate. The compression screw and fixing nut are designed with a reliable self-locking helix angle, which ensures reliability and stability during compression. At the same time, automatic control is achieved with a comprehensive motor protector, which can protect the motor from overheating and overload.





Product Features


- A. Filtration pressure < 0.5 Mpa
- B . **Filtration temperature:** 45°C/ room temperature; 80°C/ high temperature; 100°C/ High temperature. The raw material ratio of different temperature production filter plates is not the same, and the thickness of filter plates is not the same.
- C-1. **Discharge method open flow:** Faucets need to be installed below the left and right sides of each filter plate, and a matching sink. Open flow is used for liquids that are not recovered.
- C-2. **Liquid discharge method close flow:** Under the feed end of the filter press, there are two close flow outlet main pipes, which are connected with the liquid recovery tank. If the liquid needs to be recovered, or if the liquid is volatile, smelly, flammable and explosive, dark flow is used.
- D-1. **Selection of filter cloth material:** The pH of the liquid determines the material of the filter cloth. PH1-5 is acidic polyester filter cloth, PH8-14 is alkaline polypropylene filter cloth. The viscous liquid or solid is preferred to choose twill filter cloth, and the non-viscous liquid or solid is selected plain filter cloth.
- D-2. **Selection of filter cloth mesh:** The fluid is separated, and the corresponding mesh number is selected for different solid particle sizes. Filter cloth mesh range 100-1000 mesh. Micron to mesh

conversion (1UM = 15,000 mesh---in theory).

E. Rack surface treatment: PH value neutral or weak acid base; The surface of the filter press frame is sandblasted first, and then sprayed with primer and anti-corrosion paint. The PH value is strong acid or strong alkaline, the surface of the filter press frame is sandblasted, sprayed with primer, and the surface is wrapped with stainless steel or PP plate.

Filter Press Model Guidance						
Liquid name	Solid-liquid ratio (%)	Specific gravity of solids	Material status	PH value	Solid particle size (mesh)	
Temperature (°C)	Recovery of liquids/solids	Water content of filter cake	Working hours/day	Capacity/day	Whether the liquid evaporates or not	
		July 1	11101			

Feeding process



Application Industries

It is widely used in solid-liquid separation process in petroleum, chemical, dyestuff, metallurgy, pharmacy, food, coal washing, inorganic salt, alcohol, chemical, metallurgy, pharmacy, light industry, coal, food, textile, environmental protection, energy and other industries.


Filter press ordering instructions

1. Refer to the filter press selection guide, filter press overview, specifications and models, select the model and supporting equipment according to the needs.

For example: Whether the filter cake is washed or not, whether the effluent is open or close, whether the rack is corrosion-resistant or not, the mode of operation, etc., must be specified in the contract.

- 1. According to the special needs of customers, our company can design and produce non-standard models or customized products.
- 3. The product pictures provided in this document are for reference only. In case of changes, we will not give any notice and the actual order will prevail.


Dimension Drawing of Mechanical compression filter press



Model	Filter Area m²	Plate Size	Chamber volume	Plate Qty (pcs)	Overall Weight	Motor Power	Overall dimension (mm)		Inlet Size(a)	Outlet/close flow size(b)	Outlet/open flow size	
		(mm)	(L)		Kg	Kw	Length (L)	Width (W)	Height (H)			
JYFPCH-4-450	4		60	9	830		1960					
JYFPCH-8-450	8	450	120	19	920		2465					
JYFPCH-10-450	10	×	150	24	9800	2.2	2710		900	DN50	DN50	G1/2
JYFPCH-12-450	12	450	180	29	1010		2980	700				
JYFPCH-16-450	16		240	36	1120		3465					
JYFPCH-15-700	15		225	18	1710		2665	/	- 1/-			
JYFPCH-20-700	20	700	300	24	1960		2970					
JYFPCH-30-700	30	×	450	37	2315	2.2	3610	900	1100	DN65	DN50	G1/2
JYFPCH-40-700	40	700	600	49	2588		4500					
JYFPCH-30-870	30		450	23	2380		3280					
JYFPCH-40-870	40	870	600	30	2725		3670					
JYFPCH-50-870	50	×	750	38	3118	2.2	4210	1200	1300	DN80	DN65	G1/2
JYFPCH-60-870	60	870	900	46	3512		4650	1				
JYFPCH-80-870	80		1200	62	4261		5530	1				
JYFPCH-50-1000	50		745	28	3960		4060					
JYFPCH-60-1000	60	1000×	1050	34	4510		4810	1				
JYFPCH-80-1000	80	1000	1200	46	4968	4.0	5200	1500	1400	DN80	DN65	G 3/4
JYFPCH-100-1000	100		1500	57	5685		5900					
JYFPCH-120-1000	120		1800	69	6320		6560					
JYFPCH-100-1250	100		1480	38	7960		5120			7	<u></u>	
JYFPCH-140-1250	140	1250	2090	53	8860		6090					
JYFPCH-180-1250	180	×	2665	67	9560	5.5	7010	1800	1600	DN 125	DN 80	G3/4
JYFPCH-200-1250	200	1250	2980	75	11060		7460					
JYFPCH-250-1250	250		3735	95	13850		8720	1				

Hoisting diagram of filter press

Filter board hoisting diagram



Requirements for use of filter presses

- 1. According to the process requirements to make pipeline connection, and do water inlet test, detect the air tightness of the pipeline;
- 2. For the connection of the input power supply (3 phase + neutral), it is best to use a ground wire for the electric control cabinet;
- 3. Connection between control cabinet and surrounding equipment. Some wires has been connected. The output line terminals of the control cabinet are labeled. Refer to the circuit diagram to check the wiring and connect it. If there is any looseness in the fixed terminal, compress again;

- 4. Fill the hydraulic station with 46 # hydraulic oil, the hydraulic oil should be seen in the tank observation window. If the filter press operates continuously for 240 hours, replace or filter the hydraulic oil;
- 5. Installation of cylinder pressure gauge. Use a wrench to avoid manual rotation during installation. Use an O-ring at the connection between the pressure gauge and the oil cylinder;
- 6. The first time the oil cylinder runs, the motor of the hydraulic station should be rotated clockwise (indicated on the motor). When the oil cylinder is pushed forward, the pressure gauge base should discharge air, and the oil cylinder should be repeatedly pushed forward and backward (the upper limit pressure of the pressure gauge is 10Mpa) and air should be discharged simultaneously;
- 7. The filter press runs for the first time, select the manual state of control cabinet to run different functions respectively; After the functions are normal, you can select the automatic state;
- 8. Installation of filter cloth. During the trial operation of the filter press, the filter plate should be equipped with filter cloth in advance. Install the filter cloth on the filter plate to ensure that the filter cloth is flat and there are no creases or overlaps. Manually push the filter plate to ensure that the filter cloth is flat.
- 9. During the operation of the filter press, if an accident occurs, the operator presses the emergency stop button or pulls the emergency rope;

Main faults and troubleshooting methods

Fault phenomenon	Fault Principle	Troubleshooting		
Severe noise or unstable	1. The oil pump is empty	Oil tank refueling, solve		
pressure in the hydraulic	or the oil suction pipe is	suction pipe leakage		
system	blocked.			
	2. The sealing surface of	Clean sealing surfaces		
	the filter plate is caught			
	with misc.			
	3. Air in the oil circuit	Exhaust air		
	4 . Oil pump damaged or	Replace or repair		
	worn			
	5 . The relief valve is	Replace or repair		
	unstable			
	6. Pipe vibration	Tightening or reinforcing		
Insufficient or no pressure	1. Oil pump damage	Replace or repair		
in the hydraulic system	2. Pressure adjusted	recalibration		
	incorrectly			
	3. Oil viscosity is too low	Replacement of oil		
	4. There is a leak in the oil	Repair after examination		
	pump system			
Insufficient cylinder	1. Damaged or stuck high	Replace or repair		
pressure during	pressure relief valve			

compression	2 Damaged reversing valve	Replace or repair		
	3 Damaged large piston seal	replacement		
	4 Damaged small piston "0" seal	replacement		
	5. Damaged oil pump	Replace or repair		
	6 Pressure adjusted incorrectly	recalibrate		
Insufficient cylinder pressure when returning	1 Damaged or stuck low pressure relief valve	Replace or repair		
	2 Damaged small piston seal	replacement		
	3 Damaged small piston "0" seal	replacement		
Piston crawling	Air in the oil circuit	Replace or repair		
Serious transmission noise	1. Bearing damage	replacement		
	2. Gear striking or wearing	Replace or repair		
Serious leakage between	1. Plate and frame	replacement		
plates and frames	deformation			
	2 Debris on sealing surface	Clean		
	3. Filter cloth with folds,	Qualified for finishing or		
	overlaps, etc.	replacement		
	4 Insufficient	** *		
	compression force	compression force		
The plate and frame are	1. Filter pressure too high			
broken or deformed		Appropriately lowered		
	temperature	temperatures		
	3 Compression force too	Adjust the compression		
	high	force appropriately		
	4. Filtering too fast	Reduced filtration rate		
	5. Clogged feed hole	Cleaning the feed hole		
	6. Stopping in the middle of filtration	Do not stop in the middle of filtration		
The replenishment system	1. The hydraulic control	replacement		
works frequently	check valve is not tightly			
	closed			
	2. Leakage in the cylinder	Replacement of cylinder seals		
Hydraulic reversing valve	Spool stuck or damaged	Disassemble and clean or		
failure	_	replace the directional valve		

The trolley can't be pulled	1.Low oil motor oil circuit	adjust	
back because of the back	pressure		
and forth impact.	2 The pressure relay	adjust	
	pressure is low		
Failure to follow	Failure of a component of	Repair or replace	
procedures	the hydraulic system,	symptomatically after	
	electrical system	inspection	
Diaphragm damage	1 insufficient air pressure	Reduced press pressure	
	2. Insufficient feed	Pressing after filling the	
		chamber with material	
	3 A foreign object has	foreign matter removal	
	punctured the diaphragm.		
Bending damage to main	1 Poor or uneven	Refurbish or redo	
beam	foundations		

Tel. +86 021-51863216 +86 13916593699

Email. junyifilter@junyigl.com

Address: Shanghai China

Shanghai Junyi filtration equipment Co., LTD